

# 5

## **Illustrated Parts Breakdown**

- Order Spare Parts
- Field Replaceable Unit List
- Illustrated Parts Breakdown

---

This section contains the illustrated parts breakdown (IPB) and NEC Computers part descriptions for the Intel Pentium III-based PowerMate 2000 Series systems.

The following tables list

- telephone number for ordering spare parts
- field-replaceable parts for the system.

The PowerMate 2000 Series system illustrated parts breakdown figure is at the end of this section.

## ***Order Spare Parts***

Use the telephone number in the following table to order spare parts.

### ***Ordering Parts***

<b>Item</b>	<b>Telephone Number</b>
To order spare parts (U.S. and Canada only):	1-800-632-4525

## ***Field Replaceable Unit List***

The following table lists the field replaceable units (FRUs) for the Pentium III-based PowerMate 2000 Series system. The following illustrated parts breakdown shows the FRU items.

### ***PowerMate 2000 Pentium III Processor-Based Series System FRU List***

<b>Item No. on IPB</b>	<b>FRU Description</b>
1	Intel Pentium III 933-MHz or higher Processor
2	CPU Fan
3	Heat Sink
4	Heat Sink Clip
5	Network Board Cable
6a	CD-ROM Drive
6b	Combo Drive (optional)
7	CD-ROM Interface Connector Board
8	PC Slot Dummy Card
9	PC Card Bay
10	128-MB SDRAM SO-DIMM
11	LCD Panel Assembly
12	Collar, LCD Panel
13	Hard Drive Interface Cable

---

**PowerMate 2000 Pentium III Processor-Based Series System FRU List**

<b>Item No. on IPB</b>	<b>FRU Description</b>
14	EIDE Hard Drive
15	Hard Drive Access Panel
16	Diskette Drive Interface Cable
17	Diskette Drive Assembly
18	CD-ROM Interface Cable
19	LAN Connector Board
20	Network Board
21	System Board
22	CMOS Battery

**NOTE:** The following FRU items are not shown on the IPB.

----	AC Power Adapter
----	AC Power Cord
----	Mouse (NEC or Logitech)
----	Keyboard, Ergo
----	Diskette Drive (without frame and bezel)
----	Diskette Drive Bezel
----	Slide Spacer, Chassis
----	Stand Cover, Chassis
----	Hard Drive Pull Sheet
----	Rear Cover Hinge, Chassis
----	Front Cover Hinge, Chassis
----	Rubber Foot, Chassis
----	Auxiliary Cooling Fan

---

---

## Illustrated Parts Breakdown

The following figure shows the illustrated parts breakdown (IPB) for the Pentium III-based PowerMate 2000 Series system. Each FRU on the IPB is identified with a number that cross-references to the FRU list.

*PowerMate 2000 Pentium III-Based Series System IPB*

