

1



2



3



4

Use your keyboard and mouse to follow the on-screen prompts and to complete the setup of your Microsoft® Windows® XP Tablet Edition operating system.

NOTES

Use AC power, not battery power, when following the on-screen registration and setup instructions.

Before operating your system on battery power, be sure to fully charge your battery. See the *NEC Versa LitePad Tablet PC User's Guide* for details.

See the *NEC Versa LitePad Tablet PC User's Guide* for information about setting up the stand and connecting the CD-ROM drive.